
CRIMPING GUN

TO INSTALL RING HANGERS FOR WORKSTATION USE:

- 1) REMOVE TWO SCREWS ON LEFT SIDE OF REAR ENDPLATE.
- 2) RE-FASTEN SCREWS WITH RING HANGERS ATTACHED (RINGS SHOULD BE ON LEFT SIDE WHEN VIEWING FROM REAR)
- 3) BE CAREFUL NOT TO OVERTIGHTEN SCREWS TO PREVENT GASKET FROM BEING DEFORMED.



ITEM	DESCRIPTION	PART NUMBER	QTY	
1	SCREW, BHC #1D-24 X 1"	TL77D216	4	
2	BRACKET, PUSHER HOOK	B04586	1	
3	CAP, END	B04582	1	
4	GASKET	B04583	1	
5	"O" RING	SC10	1	
6	PISTON	B04580	1	
7	BUSHING, PISTON ROD	SC102	1	
8	"O" RING	SC08	5	
9	SCREW, SET	SC23 2		
10	PLUG, MANIFOLD 1/8 - 27	1753	1	
11	PIN, ROLL	SC05	· 3	
12	ROD, PISTON	B04581	1	
13	ROLLER	B01140	4	
14	PIN, ROLLER	SC01	2	
15	SHIM, FEEDER BLADE	A03116	1	
16	SIDE PLATE (L & R)	B04584F	2	
17	NUT, NYLOCK	SC77	2	
18	SPRING, LATCH	B01438F	1	
19	WASHER, JAW BOLT	B01442	2	
20	NUT, NYLOCK	SC13	2	
21	LATCH	B04666	1	
22	JAW, UPPER	C02417F	1	
23	BUSHING, JAW	B01441	2	
24	BLADE, FEDDER	B032831F	1	
25	JAW, LOWER	C02420F	1	
26	GUARD, TRIGGER	B01435F	1	
27	TRIGGER	A02073F	1	
28	SHIM, MAGAZINE .030"	A01911	2	
29	BOLT, SPLIT SPRING	A02592	1	
	SHIM, MAGAZINE (.010")	B1545010	A/R	
30	SHIM, MAGAZINE (.005")	B1545005	7~``	
31	MAGAZINE BODY	B01991F	1	
32	BOLT, JAW	B01507	2	
33	NUT, FLEXLOK	TL727200	1	
34	SPRING, PUSHER	B01444	1	
35	PUSHER, FINISHED	B014592F	1	
36	PIN, ROLL 3/32" X 1"	SC12	1	
37	BRACKET, 1/2" SPRING SPOOL	C04585	1	
38	SCREW, SHC #10-24 X 1"	TL710216	2	
39	SCREW, BUTTON HEAD CAP	SC18	2	

STEM, THROTTLE	B01425F	1.
SEAT, FRONT VALVE	B03042	1
"O" RING	SC09	2
SCREW, SHC VALVE	SC21	2
GRIP	C03916	1
HOUSING, MACHINED	D04579F	1
SPACER, THROTTLE VALVE	B03044	1
SUPPORT, "O" RING END	B01421	4
	B01422	2
WASHER, THROTLE VALVE	B01455	2
SPRING, VALVE	B04587	1
SEAT, REAR VALVE	B03043	1
DEFLECTOR, AIR	B01426	1
WASHER, SPRING	B01891	1
	SEAT, FRONT VALVE "O" RING SCREW, SHC VALVE GRIP HOUSING, MACHINED SPACER, THROTTLE VALVE SUPPORT, "O" RING END SUPPORT, "O" RING CENTER WASHER, THROTLE VALVE SPRING, VALVE SEAT, REAR VALVE DEFLECTOR, AIR	SEAT, FRONT VALVE B03042 "O" RING SC09 SCREW, SHC VALVE SC21 GRIP C03916 HOUSING, MACHINED D04579F SPACER, THROTTLE VALVE B03044 SUPPORT, "O" RING END B01421 SUPPORT, "O" RING CENTER B01422 WASHER, THROTLE VALVE B01455 SPRING, VALVE B04587 SEAT, REAR VALVE B03043 DEFLECTOR, AIR B01426

"A/R" DENOTES AS REQUIRED FOR OPTIMUM PERFORMANCE

ASSEMBLIES
DESCRIPTION ITEMS INCLUDED
CYLINDER HOUSING COMPLETE
(SMALL SC7) AD04579F

7,8,10,44,45





For sales, service and spare parts

www.apm-mouldings.com.au

Australian Owned Family Company
Quality Moulding Manufacturers and Distributors





FOR ORDERS
Available 24/7







